

# TABLE OF CONTENTS

- 1. Lecture context
- 2. Object prefixes
- 3. General Programming Understanding
- 4. Properties
- 5. Methods
- 6. EVENTS & HANDLERS
- 7. FORM OBJECT
- 8. Textbox Control
- 9. Command Button Control
- 10. Writing comments in Visual Basic
- 11. DEBUGGING IN VISUAL BASIC
- 12. STRING Concatenation in visual Basic

#### LECTURE CONTEXT

- Most programs run in Object Orientated graphical environments these days such as Windows, Mountain Lion, Linux, etc.
- Graphical environments are based around a GUI model and all visible items are visual representations of some code that programmers and users can modify and utilise.
- These visible items are instances of Classes (sort of a genus name such as 'birds') and are called Objects.
- They may be manipulated via Properties and Methods by the user or programmer, and it is essential that students are familiar with these concepts before we move onto actual programming.




# **OBJECT PREFIXES**

Names must start with a letter (max 255)
Capitalise and Prefix object names as follows (assessed):

Prefix	Object	Example use
cbo	Combobox	cboUserChoice
chk	Checkbox	chkUserSelection
cmd	Command Button	cmdStart
dat	Data	datMyDataFile
dir	Directory list	dirUserDirectory
dlg	Common dialog	dlgPrintFile
frm	Form	frmStartupForm
Gr	Graphics Object	grForm
txt	Textbox	txtDataEntryBox
Btn	Button	btnOk

#### PROPERTIES

- Set characteristics and/or appearance of an Object (occasionally functionality too)
- All Objects support them and expose many to programmer
- May be manipulated/set at both **DESIGN TIME** (when writing code) or **RUN TIME** (user interaction)
- Typical: Size, Colour, Font, Text, Name....
- Format is **Object.Property**
- Some properties are read only at run time (e.g. Bold and Italic for Textbox)



an object's title bar or below an

#### GENERAL PROGRAMMING UNDERSTANDING

#### **Accessing Properties**

- picPicture1 is a Class / Object in this example
- When u use the dot notation, you are accessing the internal variable inside of it
- Writing it in this manner would mean assigning the value to the inner variable
- Also known as variables in other programming languages

#### **Accessing Methods**

- picPicture1 is a Class / Object in this example
- When u use the brackets at the end u are trying to access a method
- Writing it in this manner would mean assigning the value to external variable
- Also known as functions in other programming languages

e.g. picPicture1.BackColor = Color.Red

e.g. myResult = picPicture.getColor()

#### **PROPERTIES**

- Name used to access the control's properties and methods Design Time ONLY
- BackColor background colour for text or graphics
   e.g. picPicture1.BackColor = Color.Red
- ForeColor usually pen or text colour
   e.g. picPicture1.ForeColor = Color.Black
- Text Sets a message in a textbox or reads text from one e.g. txtTextBox.Text = "Hello World"





**METHOD** 

Do something: function & procedure

#### METHODS

- Procedures that operate on an Object
- May change the values of Properties
- Returns a value and accepts arguments
- General format is: Object.Method
- Arguments are separated by commas:
- E.g. draw a red circle with diameter 100

Dim grForm As Graphics = Me.CreateGraphics()
Dim ellipse\_pen As New Pen(Color.Red, 3)
grForm.DrawEllipse(ellipse\_pen, 0, 0, 200, 200)



#### **PROPERTY**

Attribute or state

#### METHOD


Do something: function & procedure


### METHOD EXAMPLE

Object METHOD
Looks like a property doesn't it?

grForm.DrawEllipse(ellipse\_pen, 0, 0, 200, 200)

Ellipse(circle) defined in a rectangle with top left coordinates 0,0 and diameter 200





#### EVENTS

- Trigger an object's reaction to external or internal stimuli
- Windows monitors for events and 'flags' occurrence to objects not instantaneous
- Response code = EVENT HANDLER
- No Event Handler code= no response
- e.g clicking the command button runs:
   Private Sub Button1\_Click(ByVal sender As System.Object, ByVal e As System.EventArgs)
   Handles Button1.Click

\*Note underlined section beyond scope of the module

"Button1\_Click" is just a name, "Handles Button1.Click" defines the event it handles

#### **EVENTS**

Code Example

- An event handler may respond to several events which can be very useful
- Only the event Handler definitions need modification
- These visible items are instances of Classes (sort of a genus name such as 'birds') and are called Objects.
- E.g. to respond to 3 different button click event calls using a single event handler

Private Sub Button1\_Click(ByVal sender As System.Object, ByVal e As System.EventArgs)

Handles:

btnButton1.Click,


btnButton2.Click,

btnButton3.Click

# Linear and Event Driven

Start Study Hard Exit Revise University NO Passed Passed Resit! Exams? Resits? YES YES Move on to next year's study

❖ Linear algorithm ❖ Event driven algorithm:



#### EVENTS AND HANDLERS

- Typical events include: Click, Double click, Mouse down/up, Key Down etc...
- Event Handler code resides in subroutines

Private Sub Button2\_Click(ByVal sender As Object, ByVal e As System.EventArgs)
Handles btnSendMessage.Click


txtTextBox1.Text = "Hello"





#### FORM OBJECT

- Basis for most VB apps.
- One may have multiple forms in an application
- Supports many events
- Most important event handler is under the <u>Load Event</u>
  - run at application startup
  - initialization of variables and equipment
  - similar to onlnit on other programming languages



#### TEXTBOX CONTROL

- Gather user input or display program output most applications use Textboxes
- Typical properties: dimensions, position, bold, italic, index (control array), password box (\*\*\*\*\*\*), colour, scrollbars...
- Supports MULTILINE property (default=False)

This is a textbox with its multiline property set to TRUE - a simple word processor!

### TEXTBOX CONTROL

To display text, set property

Private Sub Button1\_Click\_1(...) Handles Button1.Click txtTextbox1.Text = "Hello World" End Sub To read and store text, equate a variable to the object's property

End Sub

Private Sub Button1\_Click\_1(...) Handles Button1.Click

Dim strMyString as String

strMyString = txtTextbox1.Text

#### COMMAND BUTTON CONTROL

- Default Event trigger by clicking mouse on button
- Typical properties: dimensions, position, bold, italic, index (control array), password box (\*\*\*\*\*\*), colour, scrollbars...
- Supports MULTILINE property (default=False)
- Other events: key up, key down, mouse up, mouse down, got focus, lost focus
- Methods: Move, refresh, drag, set focus

Private Sub btnCommand1\_Click()

- txtTextbox1.Text = "Hello World"
- End Sub

# COMMAND BUTTON CONTROL

- Supports many properties: style, back color, captions, down picture, enabled, font, size, position...
- Changing color requires style = Graphical
- All can be set at design time or dynamically at runtime



#### WRITING COMMENTS IN VISUAL BASIC

#### Visual Basic Comments Example

Following is the example of defining the comments in Visual Basic programming language.

```
Module Module1
Sub Main()
' Calling Method to Show Greet Messaging
GreetMessage()
Console.WriteLine("Press Any Key to Exit..")
Console.ReadLine() ' This method to read the commands from a console
End Sub
' This Method will display the welcome message
Public Sub GreetMessage()
Console.WriteLine("Welcome to Tutlane")
End Sub
End Module
```

#### DEBUGGING IN VISUAL BASIC

- Use Console.WriteLine(variableName)
- Or System.Diagnostics.Debug.WriteLine(variableName)
- To debug ur output
- In programming languages like python we would use print() to check our output

```
Dim strMyString As String

Oreferences
Private Sub Button1_Click(sender As Object, e As EventArgs) Handles btnSendMessage.Click
strMyString = txtTextBox1.Text
Console.WriteLine(strMyString)
System.Diagnostics.Debug.WriteLine(strMyString)
End Sub
End Class
```

# STRING CONCATENATION IN VISUAL BASIC

Concatenation operators join multiple strings into a single string. There are two concatenation operators, + and &. Both carry out the basic concatenation operation, as the following example shows. VB Copy Dim x As String = "Mic" & "ro" & "soft" Dim y As String = "Mic" + "ro" + "soft" ' The preceding statements set both x and y to "Microsoft". These operators can also concatenate String variables, as the following example shows. VΒ Copy Dim a As String = "abc" Dim d As String = "def" Dim z As String = a & d  $Dim \ w \ As \ String = a + d$ ' The preceding statements set both z and w to "abcdef".

https://docs.microsoft.com/en-us/dotnet/visual-basic/programming-guide/language-features/operators-and-expressions/concatenation-operators

# STRING CONCATENATION IN VISUAL BASIC

#### **Differences Between the Two Concatenation Operators**

The <u>+ Operator</u> has the primary purpose of adding two numbers. However, it can also concatenate numeric operands with string operands. The + operator has a complex set of rules that determine whether to add, concatenate, signal a compiler error, or throw a runtime <a href="InvalidCastException">InvalidCastException</a> exception.

The <u>& Operator</u> is defined only for string operands, and it always widens its operands to string, regardless of the setting of option strict.

The <u>& Operator</u> is recommended for string concatenation because it is defined exclusively for strings and reduces your chances of generating an unintended conversion.

Can be written in this manner, example shown below

```
O references

Private Sub Button3_Click(sender As Object, e As EventArgs) Handles button3.Click

strMyString = txtTextBox1.Text + " " + txtTextBox2.Text


System.Diagnostics.Debug.WriteLine(strMyString)
```

https://docs.microsoft.com/en-us/dotnet/visual-basic/programming-guide/language-features/operators-and-expressions/concatenation-operators

# EXERCISE (10 – 15 MINUTES)

#### To create a mini application

- Input name button on click must print in visual studio output
- 2. Input id button on click must print in visual studio output
- 3. When I click button result it should print out the name field with a space followed by the ID



```
Show output from: Debug

'exercise_1.exe' (CoreCLR: clrhost): Loaded 'C:\Program Files\dotnet\sh'
'exercise_1.exe' (CoreCLR: clrhost): Loaded 'C:\Program Files\dotnet\sh'
Jack
1010
Jack 1010
The thread 0x2b98 has exited with code 0 (0x0).
```